Support Group Application Note
Number: 055
Issue: 1
Author:

Saving Timpaint onto a blank disc

Applicable Hardware : BBC Master Compact

Related Application Notes:

Support Group
Acorn Computers Limited
Acorn House
Vision Park
Histon
Cambridge CB4 4AE

Saving Timpaint onto a blank disc.

Load **Timpaint** from Welcome disc.

Create your picture.

Remove the Welcome disc and insert the blank disc.

Press S, this gives the message: Filename:

Type the following: :0.Fred <return>
(where Fred is the filename)

To load the file you wil need to type in :0.Fred

NB When the blank disc is inserted pressing R will not return you to a blank Timpaint screen. To do that you must replace the Welcome disc.